

Procedure to Access **Agfa Xcalibur Usage Data**

- Locate the unidiag program on your computer

- Click on Tools

- On the drop down menu - click on Operational Statistics

- A screen will appear that indicates "Plates Used"
and "Laser Usage"